

RHIC ps Group Warm Up Work

- 1) Cold Hi-pot
 - a) 3HRS
- 2) Disconnect Magnet cables from IR ps's & Install warm up heater PLC's & Prepare qd's for warm up mode
 - a) 1-2 days
- 3) Turn On Warm up Heaters (CRYO) - check all operational, troubleshoot(CRYO and PS)
 - a) 1-2 days or more
- 4) Warm Up (CRYO)
 - a) About 10 days
- 5) After warm up complete, warm hi-pot and magnet diode checks
 - a) 1-2 days